### 1. Разяснения относно курсовия проект

- Курсовият проект ще се вземе предвид само ако са предадени необходия брой домшни.
- За курсовия проект ще ви трябват 3 виртулани машини.
- Използвайте само Windows 7 и Windows 2008 R2! Инструментът за оценяване няма да работи коректно с други версии!
- Следвайте много внимателно инструкциите. Много е важно всички имена и настройки да се копират точно както са в инструкциите!
- Ако някоя настройка не е изрично указана, използвайте стойностите по подразбиране.
- Инструментът за оценяване има три бутона, като на всеки от тях пише за коя виртуална машина е предназначен. След натискане на бутона изчакайте и ще видите генериран файл в директорията на инструмента.
- Генерираните файлове за всяка машина трябва да се архивират в един архив.
- Курсовият проект се предава през системата на Telerik, като домашно.

### 2. Инструкции

#### 2.1 Server DC01

Step	Additional Notes
Create new virtual machine	VM Minimum requirements:
	- 1 CPU
	- 768 RAM
	- 15 GB (Expanding/Thin Disk)
	<ul> <li>Network Adapter (Isolated/Internal Net)</li> </ul>
2. Install Windows 2008 R2 Standard Edition	Select Full installation option
3. Configure server name: DC01	
4. Set static IP Address configuration	192.168.75.10
	255.255.255.0
5. Enable Remote Desktop	
6. Disable Windows Firewall for all profiles	
7. Set Windows Service "Windows Audio" to	
disable	
8. Install Active Directory Domain Services Role	
9. Promote server to a domain controller	Create new Domain in new Forest
	Domain name: <yourtelerikusername>.local</yourtelerikusername>
	Forest and Domain Functional Level: 2008 R2
10. Create OU Structure	-domin.local
	- BG
	- Users
	- Computers
	- Groups
	- UK
	- Users
	- Computers
	- Groups

		LIC
		- US
		- Users
		- Computers
		- Groups
		- Global Groups
4.4		- Admin Users
11.	Create Accounts and Groups	Create the following accounts and groups:
		Global Groups/Global Admins
		Global Groups/All Finance Users
		BG/Groups/BG Finance Users
		UK/Groups/UK Finance Users
		BG/Users/Ivan.Dimitrov
		BG/Users/Denislav.Petkov
		UK/Users/Moyra.Kelly
		UK/Users/John.Smith
		Admin Users/Petar.Ivanov
		Admin Users/Ivan.Georgiev
		Admin Users/Johny.Thompsan
12.	Add users and groups nesting	Add Petar.Ivanov, Ivan.Georgiev and
		Johny.Thompsan to Global Admins
		Add Ivan.Dimitrov and Denislav.Petkov to <b>BG</b>
		Finance Users
		Add BG Finance Users and UK Finance Users to All
		Finance Users
		Fillance Osers
13.	Enable Active Directory Recycle Bin	
14.	Create GPO AppLocker	GPO Name: GlobalAppLockerPolicy
	• • • • • • • • • • • • • • • • • • • •	GPO Settings:
		Enable Applocker
		Enforce rules for all categories
		Create default rules
		GPO Links: Link the GPO to BG/UK/US OUS
15.	Create GPO DesktopPolicy	GPO Name: GlobalDesktopPolicy
10.	create of o beautopi only	GPO Settings: Set custom desktop background
		image
		_
		GPO Links: Link the GPO to the domain
16	Find the Domain SID of your domain	GPO Links: Link the GPO to the domain
16.	Find the Domain SID of your domain	Find the domain SID and save it in
16.	Find the Domain SID of your domain	Find the domain SID and save it in C:\domainSID.txt
	•	Find the domain SID and save it in C:\domainSID.txt The file should contain only the domain SID!
16. 17.	Find the Domain SID of your domain  Install File Service Role	Find the domain SID and save it in C:\domainSID.txt The file should contain only the domain SID! Install File Service Role and select:
	•	Find the domain SID and save it in C:\domainSID.txt The file should contain only the domain SID! Install File Service Role and select: DFS Namespace role service
17.	Install File Service Role	Find the domain SID and save it in C:\domainSID.txt The file should contain only the domain SID! Install File Service Role and select: DFS Namespace role service File Server Resource Manager
	•	Find the domain SID and save it in C:\domainSID.txt The file should contain only the domain SID! Install File Service Role and select: DFS Namespace role service File Server Resource Manager Location: C:\Shared Documents
17.	Install File Service Role	Find the domain SID and save it in C:\domainSID.txt The file should contain only the domain SID! Install File Service Role and select: DFS Namespace role service File Server Resource Manager

19. 20.	Create new DFS Namespace Create DFS Link Target (New Folder)	NTFS Permissions:  Deselect — "Include inheritable permissions from this object's parent"  Add Administrators — Full Control  Add Authenticated Users — Read  Add All Finance Users — Modify  Name: DATA  \\domain\DATA\SharedDocs -> \\DC01\Shared Documents
21.	Set folder quota on C:\Shared	Set Hard Quota 300 MB
Doc	cuments	Name the quota template "300.00 MB (Hard)"

## 2.2 Server SRV01

Step		Additional Notes
1.	Create new virtual machine	VM Minimum requirements:
		- <b>1</b> CPU
		- <b>768</b> RAM
		- <b>30 GB</b> (Expanding/Thin Disk)
		<ul> <li>Network Adapter (Isolated/Internal Net)</li> </ul>
2.	Install Windows 2008 R2 Standard Edition	Select Full installation option
3.	Configure server name: SRV01	
4.	Set static IP Address and DNS	192.168.75.11
		255.255.255.0
		DNS: 192.168.75.10
5.	Join server in the domain	
6.	Enable Remote Desktop	
7.	Disable Windows Firewall for all profiles	
8.	Install DHCP Role	
9.	Create new DHCP Scope	Scope Settings:
		Range: 192.168.75.1 – 192.168.75.254
		Exclusion: 192.168.75.1 – 192.168.75.128
		DNS: 192.168.75.10 (Set DNS on Scope Level!)
10.	Install WDS Role	
11.	Add Boot and Install Images	Add WIMs from Windows 2008 R2
		Set default names for Install Images

12. Create Capture Image	Set capture image name "Capture" and filename "capture.wim"
13. Create new user defined Performance Monitor DataCollectorSet	Name: CPUandMemory Add Performance counters:
	<ul> <li>Processor: %Processor Time</li> </ul>
	<ul> <li>Memory: Available Mbytes</li> </ul>

## 2.3 Client machine CL01

Step		Additional Notes
1.	Create new virtual machine	VM Minimum requirements: - 1 CPU
		- 768 RAM
		- 15 GB (Expanding/Thin Disk)
		<ul> <li>Network Adapter (Isolated/Internal)</li> </ul>
2.	Install Windows 7	Ultimate or Enterprise
3.	Configure name: CL01	
4.	Set dynamic IP and DNS configuration	
5.	Join workstation in the domain	
6.	Disable Windows Firewall for all profiles	
7.	Run Sysprep	Select OOBE and Generalize options
8.	Shutdown Workstation	
9.	Boot Capture Image	
10.	Capture Win7 Image and upload it on the WDS	Set image name "Win7Prep" and description "Win7Prep"

# 2.4 Capture all configurations

Step		Additional Notes
1.	Download ExamAssessmentTool	
2.	Copy ExamAssessmentTool to each VM	
3.	Run ExamAssessmentTool on each VM	
	and select the proper button	
	(computername)	
4.	Copy all output files to a single folder	
5.	Create zip file that contains all output files	
6.	Upload the zip file as homework in the	
	Telerik Academy system	